



Subject: Release Note for 3.61a VGA Driver Logo

MID for WinXP & Win2K: **866961**

[Win2000/XP_DDraw 3.61a.02]

1. Fix bug -- Color setting becomes unusual and set default value incorrect.
→ Make driver follow H/W design rule, don't allow user to turn on/off "Color Enhancement" dynamically.

[Win2000/XP_Utility 3.61a.02]

1. Fix bug – Show incorrect String in Multi-language OS.
2. Fix bug -- Using CD-ROM to install driver, need to wait 20 min

[Win2000/XP_2D 3.61.51]

1. Fix bug -- We select a background picture "Chateau" as Wallpaper, there will appear incorrect lines in Win2000 1600*1200*8bpp mode.
2. Fix bug -- LCD will black when change to TV only by hotkey and shutdown then boot
3. Fix bug – There is a glitch noise on LCD power at going S3 mode
4. Fix bug – Connect SXGA monitor and set resolution as SXGA. The screen corrupts after change to WXGA monitor.
5. Modify M760 support mode based on M760 APnote "AM760-005".

[Win98/ME_2D 3.61.51]

1. Fix bug -- Cannot play DVD under Win98/ME
2. Modify M760 support mode based on M760 APnote "AM760-005".

[Win2K/XP_DDraw 3.61.51]

1. Fix bug -- When play DVD by WinDVD and change the color setting, it will be back to the SiS value.
2. Fix bug -- The video is corrupted when play DVD title with Window Media Player.
3. Fix bug -- Movie title screen would flash briefly.

[Win2000/XP_Utility 3.61.51]

1. Fix bug – Some description of Utility are wrong in German
2. Fix bug -- Some description of Utility are wrong in Russian
3. Fix bug -- Some description of Utility are wrong in Japanese



[Win2K/XP_DDraw 3.61.02]

1. Fix bug -- Display hang or corrupted on AP "Stretch EYE Hyper LE"

[Win2000/XP_2D 3.61.01]

1. Set single LCD up to 1400x1050, multi-mode LCD up to 1024x768 for 760 UMA.

[Win2K/XP_DDraw 3.61.01]

1. Fix bug – Play DVD with WinDVD5, the movie image goes little bit down when the subtitle appears.

[Win2000/XP_2D 3.60.00]

1. Fix bug -- Screen is nothing when play Media-Player and switch device mode by hot key.
2. Fix bug – On Win2K, CRT+TV 1024*768, TV display error when run AP "SISMV".
3. Fix bug -- Display mode can't be changed by ACPI hotkey
4. Fix bug -- Press Display devices detection when PNP LCD is attached, LCD can't enable.
5. Fix bug – On DOS Prompt Full Screen, there are no signal both on TV and LVDS screen.

[Win2K/XP_DDraw 3.61.00]

1. Fix bug -- Play WMV with Media player 9, left side have repeat display.

[Win2000/XP_Utility 3.61.00]

1. Fix bug -- Can't change display device by hotkey when resume from S4.
2. Fix bug – Hotkey function sometimes can't work.